

Si – Patine (Sponge)

Description:

Si - Patine is a glazed coating used to create decorative and attractive finish techniques. It is a water based Latex formula, it is easy to apply with a special painting tools to create the fantasy finishes like sponging, rag rolling or dragging which enhance beauty and pleasure to place.

Areas Of Use:

Si- Patine can be used for interior walls, ceilings, wood surfaces which is need very fine touch of decoration like villa, royals, receptions, restaurants, hotels, airports. Si-Patine offers long open time for negative techniques when decorating large surfaces, so it can be used to decorate on emulsion or enamel surfaces.

Si – Patine is independent surface preparation when apply thick layer with excellent filling properties will cover all minor surface imperfection.

Specification Data:

Specific Gravity	1.2 ± 0.05 Kg/L
Viscosity	100 ± 5 KU
Solid by volume	17.2 %
Finish	Flat
Coverage	25 -30 m ² / L due to condition of surface
Drying time for touch	10 - 15 min (Touch dry) at 25C°
Drying time for Recoat	35 min (Hard dry) at 25C°
Thinning	Thinned 10- 20% if needed
Thinner	Using water
Washability	More than 5000 cycle
Mode of application	By forming roll, brush, sponge
Cleaning of tools	Using water
Flash Point	Non flammable
Storage	2 Years from date of production

Surfaces Preparation:

The surfaces should be dry, clean and free from contaminates such as grease, oil, dust, which can result in poor adhesion of the paint to the surface. Use a suitable solvent for cleaning, old flaking paint or poorly bound surfaces must be removed completely.

New Surfaces:

Wood Surfaces:

Prepare surface by use one coat of diluted Luxury under coat 313, then one coat of Latex wall putty and finish preparation with two coats of Luxury super enamel 900 or Gold Crown 300, then allow the surface to dry and apply Si- Patine with selected application tool.

Cement And Gypsum Surface:

Prepare the surface with one coat of Latex sealer 1800, then one coat of Latex wall putty and finish preparation with two coats of Bond 2000 or Duracril 5000, then allow the surface to dry and apply Si-Patine with selected application tool.

Old Painted Surfaces:

Wood Surfaces:

Use sanding paper to release any grease or loosing materials, flaks and defected painted surface then prepared surface as on the previous new wood surface.

Cement And Gypsum Surface:

Clean up surface well with water and soaps several times, then wash with clean water to insure surface is free, fine, then allow to dry and applied as in previous new cement & gypsum surfaces.

System Of Application:

Wood surfaces	
Product	No. of coats
Undercoat 313	1
Latex Wall Putty	2
Luxury Super Enamel 900 or Gold Crown 300	2
Si- Patine	1

Cement & Gypsum Surfaces	
Product	No. of coats
Sealer 1800	1
Latex Wall Putty	2
Duracril 6000 or Bond 2000	2
Si- Patine	1

Safety For Use:

- 1- Keep away from direct sunlight with good ventilation.
- 2- Keep out of reach of children and direct flame.
- 3- Avoid eye contact and skin for a long time, if it happened, wash thoroughly with fresh water immediately.