

# Quick Dry Enamel

## Description:

A high gloss fast dry, modified alkyd coating which can be applied on unprimed steel wooden surfaces.

## Areas Of Use:

Suitable for one coating application to new and reconditional metal drums and all steel and wooden surfaces where short handling and stacking times are required or no baking facilities are available.

## Specification Data:

Specific Gravity	1.12 Kg/L
Viscosity	85 KU
Finish	Gloss
Coverage	12 – 13 m <sup>2</sup> / L with a thickness on 30 micron due to condition of surface and tools of application
Drying time for touch	30 min (Touch dry) at 25C°
Drying time for Recoat	2 hours (Hard dry) at 25C°
Thinning	Up on need:10-20%
Thinner	Sipes spirit
Mode of application	Roller, brush, air spray
Cleaning of tools	Using water
Flash Point	26C°
Storage	2 Years from date of production

## Surfaces Preparation:

The surfaces should be dry, clean and free from contaminates such as grease, oil, dust, which can result in poor adhesion of the paint to the surface. Use a suitable solvent for cleaning old flaking paint or poorly bound surfaces must be removed completely.

## Painting New Surface:

Product	No. of coats
Quick Dry Enamel	2

## Old Steel Painted Surface:

Product	No. of coats
Antirust First	1
Quick Dry Enamel	2

## Safety For Use:

- 1- Keep away from direct sunlight with good ventilation.
- 2- Keep out of reach of children and direct flame.
- 3- Avoid eye contact and skin for a long time, if it happened, wash thoroughly with fresh water immediately.